

27618 - LA-RCH4MD-8-24 Operating Instructions & Precautions 06162303

Charging: This product is rechargeable. Please charge fully before first use to ensure optimal performance.

Plug the large connector of the included charging cable into any USB power source such as a power cube, computer or car charger. Pull back the charging port cover on the bottom of the light and insert the micro-USB plug. The power switch flashes green while charging and solid green when fully charged. Remove the charging cable and replace the charging port cover.

Head Strap Installation: Locate the top mounting prongs on the light. Note that one of the prongs is longer than the other. With the black side of the head strap facing up, slip the loop of the single ended strap onto the longer prong. Scrunch the remaining portion of the loop and slide it over the shorter prong. Repeat the process for the left and right side loops. Use the adjustment sliders on the top and side to fit.

Operation: Repeatedly pressing the power button cycles between high and low white, solid red, and flashing red light modes and off.

Caution! This product contains a non-replaceable rechargeable lithium battery. Attempting to open the product or replacing the rechargeable battery will result in permanent damage and void all warranties.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions!