

27632 - LA-400NECK-6-12 Operating Instructions & Precautions 06062303

Charging: This product is rechargeable. Please charge both lights fully before first use to ensure optimal performance. Plug the full sized USB plug of the included charging cables into any USB power source such as a power cube, computer or car charger. Pull back the charging port cover on each light located on the opposite side of the On/Off switch and insert the USB-C connector of each charging cable. A red light on each power button indicates charging is in progress. Charging is complete when the light turns green on both buttons. Remove the charging cable and replace the charging port cover. **NOTE:** You may charge each light independently. Charging may be done with the lights in or out of their holders.

Operation: Repeatedly pressing the power button cycles between high and low brightness modes, and off. You may adjust the flexible holder in any direction while neck worn or free standing. Individual lights may be easily removed from their magnetic holders and used as hand-held flashlights. A push-pull focus on each light helps direct light where you need it.

Caution! This product contains a non-replaceable rechargeable lithium battery. Attempting to open the product or replacing the rechargeable battery will result in permanent damage and void all warranties.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions!